



"WATER PROOFING SEQUENCE."

'A'




- TIMBER OR MASONARY WALL FRAME.
- WATER PROOF WALL SHEET OR RENDER.
- FIBRE GLASS MATTING @ ALL 90° JOINTS.
- FLEXIBLE WATER PROOF SEALANT @ ALL JOINTS
- PUDDLE OR LEAK CONTROL FLANGE. (FLUSH WITH THE FINISHED FLOOR LEVEL.
- F.R.C. FLOOR SHEET OR CONCRETE SLAB.
- P.V.C. PIPE CONNECTED TO SEWER.

'B'



- WATER PROOF MEMBRANE PAINTED ONTO TO ALL SURFACES & CONTINUED DOWN INTO THE THROAT OF THE LEAK CONTROL FLANGE (THIS MUST BE APPLIED BY A LICENSED CONTRACTOR & CERTIFIED).
- MORTAR BED WITH FALL TOWARD THE SHOWER GRATE.

'C'



- TILE GLUE
- FINISHED WALL TILE.
- COLOUR MATCHED FLEXIBLE WATERPROOF SEALANT. AROUND PERIMETER OF SHOWER TRAY
- STAINLESS STEEL SHOWER GRATE, FINISHED LEVEL 2-3mm BELOW THE TILE SURFACE TO PREVENT PONDING.
- OPTIONAL 2ND WATER PROOF MEMBRANE OVER MORTAR BED.
- FLOOR TILE.
- TILE GLUE.

'NOT TO SCALE'